

# DENVER®



## DENVER BTS-20 - Bluetooth Speaker

This speaker has two different modes. Either Bluetooth or AUX mode. To switch to AUX mode when on Bluetooth mode, please push and hold PLAY/PAUSE button.

### **Mode 1: Bluetooth – How to pair.**

Turn on the speaker and you will hear a beep. The light will blink blue and red. Now the speaker are ready to pair. Search after the speaker with your smartphone or pc. If needed, the standard pair code are: **0000**

### **Mode 2: AUX/direct input mode.**

Plug the mini USB plug into the speaker and the minijack plug into the item you want to play music from. Then push and hold play/pause on the BTS-20 and you are ready to play music.

### **Buttons on the speaker:**

On/Off : To turn on/off unit

Pause/Play: To pause play audio when in Bluetooth mode. Push and hold this button to change to AUX mode.

Volume +/-: Press and hold vol + to increase volume, press and hold vol - to decrease volume. Press vol+ short to change to next song, press vol- short to change to previous song.

### **Charge BTS-20:**

To charge your speaker, please connect the mini USB plug into the speaker and the normal USB plug into a PC (turned on), or into an USB adaptor (not included). This will charge the speaker. You can play music while charging, but this will make the charging period longer.

Charge time when turned off: App. 2 hours

Play time when fully charged: App. 2 hours

Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen below. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Additional information is available at the technical department of your city.

Hereby, Inter Sales A/S, declares that this product BTS-20 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the Declaration of conformity may be obtained at:

Inter Sales A/S  
Stavneagervej 22,  
DK-8250 Egaa  
Denmark



**ALL RIGHTS RESERVED**  
**COPYRIGHT DENVER ELECTRONICS A/S**  
**WWW.DENVER-ELECTRONICS.COM**

### **Importer:**

**DENVER ELECTRONICS A/S**

**Stavneagervej 22**

**DK-8250 EGAA**

**DENMARK**

**facebook.com/denverelectronics**

# DENVER®

120g铜板纸双面印刷125\*87. 96MM